Own schematic

Create your own schematic!

You haven't found your ideal schematic among our range? Then create your own based entirely on your own concept. The Megaswitch M offers you a broad range of options for many coil combinations. We'd like to help you do this. We have prepared a number of semi-complete diagrams to get you started. You can complete these using a standard digital image processing program or you can simply print it onto paper and go to work on it with pencil and eraser.

Here are some tips before you begin: Generally, you can switch the individual coils parallel to each other or in series. It is important however, to consider the **electric polarity**, similar to when using batteries. At a first glance, this may not seem to make sense, as pickups always produce AC voltage. When you are using only one coil, the polarity doesn't matter. However, when you put two or more coils together, these can work out of phase, particularly if they are made by different manufacturers. Pickups that are out of phase produce a very weak bass range. They also make your overall sound hollow and tinny. It is better to check the polarity of your pickups before you solder on the wires, to avoid any nasty surprises later.

Unfortunately, when it comes to defining the polarity of your pickup coils, the color of the wires is no indicator, because there is no standard color coding for these wires and each manufacturer pretty much does their own thing. Sometimes the color of the wires varies even on pickups made by a single manufacturer. Frequently, the following leads to confusion: The "cold" wire (ground/earth wire; black wire or shielding is defined as minus and the "hot" wire (signal output; white wire or inner core of the cable) is defined as plus. In any case, it makes sense to check each one individually, irrespective of the color of the wires.

To check the polarity, you need a simple moving coil multimeter with pointer (see figure 1), which is quite affordable and widely available in electrical supply stores. A digital device is not suitable. To begin, select the most sensitive measuring range (usually 100 mV/ 50 μ A), then connect the wires of the pickup to the device. Using an iron object such as a spanner or scissors, allow the pickup to magnetically "pull" it by holding it close to the pickup. This causes the pointer on the instrument to move a bit either to the left or to the right. When you take the metal object away again, the pointer swings to the other side. If you do this with different pickups, you can observe that some types start left, then go to the right, whereas other pickups work the other way round, i.e. they start left, then go right. In any case, when you swop the pickup wires, the direction changes, meaning a left-to-right reading will change to right-to-left.




Figure 1. Checking the electrical polarity of coils using a simple multimeter

The polarity of a coil is best defined as follows: Connect it to the instrument so that the pointer goes to the right when you let it magnetically "pull" an iron object and goes to the left when you remove it. Then the pickup wire which is connected to the positive terminal of the instrument is "positive" and the other one is "negative".

If two or more coils are combined they normally should work in phase with each other. When switching parallel, you connect plus poles to plus poles, and accordingly, minus poles to minus poles (**figure 2**). To configure in phase switching in series, connect the plus pole of one coil with the minus pole of the other (**figure 3a/b**).




Figure 2. In phase parallel switching




Figure 3. In phase switching in series

Usually, out of phase configurations are not that popular. Nevertheless, if you choose to do this, here is how to do it. Connect, in parallel switching, the plus pole to the minus pole and vice versa (figure 4a). You can make the sound a bit fatter by reducing the bass on the bridge pickup by installing a capacitor in the signal path (figure 4b). The value of the capacitor is a matter of choice, but a good start for experimenting is $0.022~\mu\text{F}$, for example. When switching in series, you connect the two plus poles or two minus poles together (figure 5 a/b). If you want to have two pickups working out of phase, then they should be placed as far away from each other as possible. On a Stratocaster, this would mean the neck and the bridge pickup; using the middle pickup combined with either the bridge or the neck pickup would make your sound much too thin.




Figure 4. Out of phase parallel switching




Figure 5. Out of phase switching in series

The two coils of one and the same humbucker always must be connected in phase, either in series (**figure 6a/b**) or parallel (**figure 6c**). It makes no sense to use out of phase connection here, neither in series (**figure 7a/b**) nor parallel (**figure 7c**). The sound produced would be much too quiet.




Figure 6. Configuring two humbucker coils correctly – always in phase




Figure 7. Not like this! Out of phase configurations of two coils on a single humbucker are unusable.

Now you can begin. Let your creativity flow. Invent new ways of wiring that no-one else has come up with until now. You don't need to have studied electronics to do it. All you need is common sense. Nothing can go wrong. One last tip: Coils that should not be active in a particular switching position can be deactivated by either switching them off, or by short-circuiting them. This gives you even more options.

Below you can find a range of semi-complete switching diagrams for seven of the most common guitar types. Each of them includes two different options for positioning your switch, depending on what suits your design best. The switching positions are as follows: 1= bottom (bridge), 2 = second from the bottom, 3 = middle, 4 = second from the top, 5 = top (neck). The symbols on the potentiometers are as follows: L = left position, R = right position, S = wiper. On right-hand guitars, the Megaswitch is located with the printed circuit facing towards the strings; on left-handed guitars it faces away from the strings.

"SSS": Three singlecoils




Figure 8a/b Semi-completed switching diagrams for three singlecoils

"HSS": One humbucker (at the bridge) and two singlecoils




Figure 9a/b. Semi-completed switching diagrams for one humbucker and two singlecoils

"HSH": humbucker, singlecoil, humbucker




Figure 10a/b. Semi-completed switching diagrams for two humbuckers and one singlecoil

"HH": Two humbuckers




Figure 11a/b. Semi-completed switching diagrams for two humbuckers

"HS": Humbucker at the bridge and singlecoil at the neck




Figure 12a/b. Semi-completed switching diagrams for a humbucker at the bridge and a singlecoil at the neck

"SH": Singlecoil at the bridge and humbucker at the neck




Figure 13a/b. Semi-completed switching diagrams for a singlecoil at the bridge and a humbucker at the neck




Figure 14a/b. Semi-completed switching diagrams for two singlecoils

Here a few examples of how to proceed. As a starting point, we use a guitar with HSH configuration. However, you can apply this to other models without difficulty. The coils which you don't have simply do not apply in the diagram, which makes everything easier.

In principle, the range of options is nearly unlimited. One very simple option is to activate just one of the coils. Then, one of the four segments of the switch is sufficient. It doesn't matter which one you use. The switching diagram for this is illustrated in **figure 15**.




Figure 15. Switching diagram for selecting one of the five coils

If you wish to switch two coils parallel in all switch positions, you need two segments, see **figure 16** for example.

- 1. Both bridge humbucker coils parallel,
- 2. The coil of the bridge humbucker nearest the bridge and the middle pickup parallel,
- 3. The coil of the bridge humbucker nearest the bridge and the coil closest to the neck of the neck humbucker parallel,
- 4. Middle singlecoil and the neck humbucker coil closest to the neck parallel,
- 5. Both neck humbucker coils parallel,




Figure 16. Choice of two coils

Usually, both coils of humbuckers are switched in series. A typical way of switching is as follows:

- 1. Bridge humbucker in series
- 2. Bridge humbucker in series, with middle singlecoil parallel
- 3. Middle singlecoil only
- 4. Neck humbucker in series, with middle singlecoil parallel
- 5. Neck humbucker in series

A switching option for the above is illustrated in **figure 17.**




Figure 17. Each humbucker operating in series

Some guitars are configured like this:

- 1. Bridge humbucker in series
- 2. Inner coil of the bridge humbucker and the middle singlecoil parallel
- 3. Middle singlecoil only
- 4. Inner coil of the neck humbucker and the middle singlecoil parallel
- 5. Neck humbucker in series

This is illustrated in **figure 18**.




Figure 18. Split humbuckers in position 2 and 4

Maybe you'd like to configure a number of pickups in series. This is also quite easy to do. To start, you can use the layout in **figure 19**. Here, all five coils are in series, and the connecting points between them are connected to the four middle contacts of the Megaswitch M. You can make as many connections as you like on the right hand side and simply short-circuit the coils which you don't need.




Figure 19. Basic principle for switching in series

Example:

- 1. Bridge humbucker in series
- 2. Inner coil of the bridge humbucker and the middle singlecoil in series
- 3. Inner coil of the bridge humbucker and the inner coil of the neck humbucker in series
- 4. Inner coil of the neck humbucker and the middle singlecoil in series
- 5. Neck humbucker in series

This is illustrated in figure 20.




Figure 20. Switching two coils in series in all five positions

With these introductory examples we hope to have fired your imagination and that you can now create your own dream switching configuration.

We wish you every success!

Your Schaller Team